

# Product Data Sheet

# **Knauf Paper Joint Tape**



Knauf Paper Joint Tape is white cellulose paper joint tape for reinforcing joints on walls and ceilings by hand or machine application, to create the strongest joints. It is recommended for use on ceilings and walls to create the strongest joints. Internal corners are made simple with a centreline for easy folding.

# **Areas of Application**

Ceilings or walls between plasterboard joints, or wherever strong joints are needed. Can be used with powdered or ready mixed jointing compound. Can also be used for patch repair work.

# **Compliance Standards**

EN 13963:2014

# **Key Benefits**

- Helps provide a strong joint to reduce the risk of hairline cracking
- Centreline makes postitioning easy, especially internal corners
- Used with Knauf Jointing Products for a complete tape
   & jointed system

#### **Performance Data**

Reaction to Fire (R2F)	Dangerous Substances	Tensile Strength
E, Reaction to Fire with jointing compound Type 3A: A2-s1, d0	NPD	Pass

# **Technical information**

		Dimensions and Weights		
Width (mm)	Length (m)	Colour	Weight (kg)	Material Number
51	150	White/Cream	1.2	258337

Creation Date: 31/08/2023 Revision Reference: 001 Revision Date: 31/08/2023

### www.knauf.co.uk



#### **Sustainability**

Recyclability

Fully recyclable

#### Storage and Handling

No special education is required for safe handling. Avoid damp conditions for storage.

#### **Packaging**

Packaged in an outer cardboard box.

#### **Disposal/Repair**

Any excess leftover product can be saved for another project or recycled in accordance with local authority requirements. Paper Joint Tape which has joint compound on should be disposed of according to the requirements of the joint compound.

#### **Health & Safety**

No special precautions are necessary but the use of gloves are recommended during the handling and installation of this product.

## **Application / Installation**

To use to complete tape and jointing finishes to tapered edge plasterboard: Use a minimum of 1mm of Knauf jointing compound (joint filler premium/joint cement premium or fill& finish) to bed the tape and fill to the shoulder of the taper of the plasterboard. Add a liberal coat of Knauf Joint Filler Premium over the top, fill the joint to the shoulder of the taper. Smooth and allow to set. Once set, apply Knauf Joint Cement Premium or Fill & Finish Light over the entire layer to approximately 50mm extra either side of the first coat and leave to dry. Repeat, and when fully dry sand if needed.

#### **Additional Documentation**

Declaration of Performance UKCA Declaration of Performance CE Safety Data Sheet







CERTIFIED

Knauf UK GmbH Company Accreditations:

ISO 45001 Occupational Health and Safety CERTIFIED

ISO 50001 inergy Management CERTIFIED



#### **Customer Service**

UK Tel: 0800 521 050 Eire Tel: 01 4620739 Email: cservice@knauf.com

#### **Technical Service**

0800 521050 (option 2) Live Webchat 09:00 -17:00 technical-uk@knauf.com

#### Website

www.knauf.co.uk www.knauf.ie

#### **Address**

Kemsley Fields Business Park Sittingbourne Kent ME9 8SR

The information given in this publication is believed to be current and accurate as at the date of publication, but no warranty, express or implied is given. Updates will not be automatically issued. © Copyright Knauf 2023

Creation Date: 31/08/2023 Revision Reference: 001 Revision Date: 31/08/2023